

# **Doremi CineLister Procedures**

AMC 🖂 AMC Classic 🖂

AMC Dine In

#### **PURPOSE**

This document provides basic knowledge necessary for using the CineLister software. CineLister is software that runs on Doremi servers and can be used for content ingestion, show management, and manual playback. These basic functions will normally happen automatically by Screenwriter or Sony TMS but can be done on the individual server at the projector if necessary.


#### **PROCEDURES**


#### **Ingesting Content**

- 1. Click Start and navigate to Doremi Apps > Ingest Manager.
- 2. **Select** the ingest source from the drop-down. The content for a USB device plugged into the Doremi shows under Local Storage.
- 3. Select to highlight the content to ingest and click Ingest.

#### **Creating or Modifying a Show Playlist**

- 1. Click Start and navigate to Doremi Apps > CineLister.
- 2. **Ensure** that manager is on the Editor tab. A screenshot of the editor tab is shown below:





- 3. **Create** a new playlist (**select** New) or open an existing playlist (**select** Open) to populate the SPL pane on right side of the screen. **Save** changes before creating/opening a new playlist to avoid losing work already done.
- Create or modify the SPL in the following ways:
  - Adding Content/Elements: Select element from left pane and select Add to Show Playlist. The element will now appear in the right SPL pane. Available content may be refreshed using the refresh button which will appear red if an update is available.
  - Removing an element: In Show Playlist window, select element to remove and click Remove.

Theatre SOP Section Number: SS-3-30
Revised: 06/04/18 Page 1 of 3



# **Doremi CineLister Procedures**


AMC 🖂 AMC Classic 🖂

AMC Dine In


- Changing the order of elements: Select element to move, then select one of the two arrow buttons located at the top of the screen.
- Playing a 2D SPL in 3D Mode: To play 2D content in 3D mode, on the Properties screen, change the SPL from "2D" to "3D."
- 5. Save the playlist by selecting Save. If saving a new SPL, the manager will be prompted for an SPL name.

### **Manual Playback**

- 1. Click Start and navigate to Doremi Apps > CineLister.
- 2. Near the bottom of the screen, **select** Playback tab.
- 3. In the upper left corner, select Manual. Once Manual mode is toggled, playback controls will be visible.
- 4. **Click** on playback controls as needed.
  - Note The Show Playlist progress bar (lower bar) indicates progression within the full SPL, the Clip Progress bar (upper bar) indicates remaining time within the current clip being played.



5. When in Pause mode, associates have the ability to skip to the previous/next clip within the SPL and skip forward/backward in three minutes increments. The buttons required to perform these operations are illustrated here.



6. Click Play button to restart the playback after selecting the desired start time.

Theatre SOP Section Number: SS-3-30
Revised: 06/04/18 Page 2 of 3



## **Doremi CineLister Procedures**


AMC 🖂 AMC Classic 🖂

AMC Dine In


### **Show Management**

CineLister may be used to view and manage SPLs if TMS is not available. Manually manipulating scheduled shows while the TMS is available and monitoring the system may result in unexpected consequences.

- 1. Click Start and navigate to Doremi Apps > CineLister.
- 2. At the bottom of the screen, **select** Schedule tab. **Use** the arrow button on the right to select the week to view/modify.



3. To add a Show Playlist to the schedule, **click** New and **select** the Show Playlist to add. The manager may be asked for a password ("Doremi"), followed by a screen which will allow them to apply the SPL to a specific schedule.



- 4. Click Save and return to the Schedule tab which will now display the updated schedule.
- 5. To delete a Show Playlist from the schedule, simply select it. It will be reverse highlighted and **click** Delete. The manager will be asked for a password ("Doremi").

Theatre SOP Section Number: SS-3-30
Revised: 06/04/18 Page 3 of 3